

# **Strongback Splice Details**





Bridging members should be continuous over as many trusses as possible with the end truss staggered and spliced.

## **Alternate Strongback Attachment**



Strongback shall be installed according to the details.

#### **Detail C**

Place strongbacks on bottom chord or top chord, and connect to vertical web with 3 - 3" common spiral nails.

### **Detail D**

End Detail: Connect each end of strongback to gable ladder vertical webs using 3 - 3" common spiral nails.

**Splice Detail:** Splice connected to strongback with 12-3" common spiral nails equally spaced along splice.

#### Detail E

Fasten strongbacks to bottom chord or top chord using 2-3" #8 screws. This method may be used only with maximum strongback size of 2x6. Locate screws <sup>3</sup>/<sub>4</sub>" from the edge of chord. Floor Truss length without strongback must not exceed 11 ft even if the truss passes vibration check.



Calgary Region

